








ПРЕСС ДЛЯ ПИЦЦЫ APACH APRESS33, APRESS45

















Pos.	FORMATRICE FP33	FORMATRICE FP45
1	S40LT60014	S40LT60018
2	S40PS23011	S40PS60001
3	S66IV60001	S66IV60002
4	S40PS23013	S40PS60003
5	S61PB60005	S61PB60003
6	S56PE60001	S56PE60002
7	S56PF60003	S56PF60004
8	S74AL60017	S74AL60019
9	S56SR60003	S56IE60001
11	S74CU60019	S74CU60023
12	A87RZ66013	A87RZ66012
13	S80PB60014	S80PB60005
14	A99PB60022	A99PB60025
14.1	S70IE60012	S70IE60013
15	S39SR60019	S39SR60023
16	S80ST60002	S80ST60001
17	S80PB60016	S80PB60018
18	A99PB60024	A99PB60027
18.1	S70SR60013	S70SR60015
19	S63VT60004	S63VT60003
20	A89CK66004	A89CK66004
21	A69FS60006	A69FS60006
22	S66FD23005	S66FD60001
23	S36PS60004	S36PS60002
24	S74AL60014	S74AL60011
25	S65CI23007	S65CI23008
26	A93OL66018	A93OL66018
27	S66FS60002	S66FS60001
28	A89RE66002	A89RE66001
29	A87MR56012 From S/N 0204538	A87MR56011 From S/N 0204538
30	S63CC60007	S63CC60010
31	A86ME24002	A86ME24002
32	A89CK66001	A89CK66001
33	S59SR60015	S59SR60018